



XR6 TURBO BATTERY / AIR BOX KIT INSTALL INSTRUCTIONS

1. Disconnect the battery terminals and remove the OEM battery. (Remember to disconnect the positive (red) battery terminal first and always keep the terminal shielded so that accidental sparking does not occur)
2. Using the PLAZMAMAN battery base, mark out 3 holes through the base onto the vehicle. Place the base as far back and left towards the driver's side of the vehicle as possible. The base has a 10 degree slope in it, and it should be positioned with the base sloping down towards the driver's side of the car.
3. Drill the 3 holes using a 7mm drill bit.
4. When mounted, the battery is positioned on its side with the terminals facing the passenger side of the vehicle. Bolt the battery onto the base from underneath and the bolt the assembly down to the vehicle.
5. Unbolt the front top guard bolt and frontal bolt holding the fuse box down and slide in the side section of the battery box. Bolt into place.
6. Clamp the silicon hose onto the turbo and then add the pipe and air-filter to fit to fit in the confines of the air-box.



7. Utilise the factory positive wire and secure it to the positive terminal. Make sure that it is secure from any possible areas that may rub through the metal. In addition, ensure the red rubber top is replaced and secure.

8. Attach the existing negative wire to the terminal and secure. (If extra length in the battery cables is required in order for them to fit correctly, simply remove the lid of the fuse box, unclip the fuse mounting and lift the fuse mounting out. The battery cables run underneath and can easily be re-routed to make use of the extra wire. Alternatively, Odyssey provides an M6 bolt thread option for their batteries. If desired the OEM negative terminal can be replaced with a 6mm ring style terminal – this is the owner's choice)
9. Start the vehicle and check the battery operation thoroughly.
10. Fit the air-box lid. If desired an extra bolt can be added to the front right hand corner for extra clamping.
11. Attach the front guard and bolt into place.



If at any point during the fit-out you are unsure of how to complete a stage, please call PLAZMAMAN and one of our highly trained technicians will be happy to assist.

Warning: It is recommended the XR6 Turbo battery/air box kit be fitted by PLAZMAMAN's qualified and highly trained mechanics, or an authorized workshop as vehicle damage & or fire may occur. If this kit is not fitted by Plazmaman, we will not be held responsible for any damage or mistakes made during the installation process. It is recommended that the XR6 Turbo battery/air box kit only be fitted to a Ford XR6 Turbo vehicle.